

CHIMNEY or SKYLIGHT FLASHING

1. Prime masonry with MFM Prime-A-Seal® and allow to dry.
2. Install Peel & Seal® in order as shown by steps.
3. Extend Peel & Seal® from eave to below chimney and from above chimney to ridge.
4. Install Peel & Seal® to form water-shedding laps.
5. Apply a continuous bead of compatible sealant along the top termination edge of Peel & Seal® on chimney and tool flat.

