

WINDOW FLASHING

1. Install WindowWrap in order as shown by steps.
2. Cut and diagonally and fold above weather resistive barrier above header to allow WindowWrap to be adhered directly to substrate.
3. Fold weather resistive barrier back over head flashing and seal with WindowWrap.
4. Never let uncured caulking come in contact with WindowWrap adhesive.

